


# HOW TO START

## Main parts



1. Antenna
2. LED Indication panel
3. On/Off button
4. Ventilation
5. AC power connection

# HOW TO USE

## Instructions

Caution: In some countries, you might need permission from the power distribution company to plug Grid Battery into the power network.

1. Install antenna.
2. Plug in the Grid Battery to the wall socket. The battery indicator should light up yellow and white while loading.
3. When adding a device for the first time to your WiFi network, install the app and follow the instructions.

## Notes

The On/Off button flashes when a WiFi AP is active.

The cooling fan is working all the time regardless of the On and Off status.

The battery level is displayed in green. When the battery is charging, there will be blue flashing, when the battery is discharging, there will be red flashing.



Do not plug Grid Battery into the power extension.



Before unplugging from the wall socket press the Turn Off button.



## Neliner App

Control the energy storage with the Neliner App.

